PREMIER
COPPER PRODUCTS

HELP LINE
877-251-4486

Skirted Vessel Sink Instructions

General Guidelines:

1) Premier Copper Products recommends using a professional installer to install our products.

2) All of our sinks are handmade and therefore dimension may vary. We recommend using the actual sink to make the template for the cutout.

3) You will need our Copper Sink Installation Silicone (item Number C900-ORB) to install the sink and drain properly. If you do not have our special color matched neutral cure silicone you can use Clear 100% Silicone (Non-water based) purchased at any hardware store.

4) Premier Copper Sink Installation silicone should be used to install the drain in the sink as well. Using plumbers putty will create a "bulls eye" effect around your dark drain due to the white color of the putty.

5) Please review the care instructions that came with your sink.
Copper cleaner should never be used on our sinks, it will strip the patina off the sink.
Use only mild, non-antibacterial soap and water for cleaning.

Skirted Vessel Sink (Half Mount)

1) Turn the sink face down on top of the countertop making sure to leave at lease 4" for the faucet. Using a pencil, trace around the sink where the sink touches the countertop. Remove the sink and draw a new line 3/4" inside the previous line. Erase the outer line.

2) Measure the outline against the sink to make sure you have everything correct before cutting. The measurements should allow the sink to drop into the cutout and the skirt rest on the counter. After verifying measurements, cut the hole out of the countertop.

3) Using the copper sink installation siilicone put a bead of silicone into the recessed area of sink drain opening. Install the drain into the sink. It is much easier to do this at this stage than after the sink is installed.

5) Place the sink into the cutout hole. Align the sink in the counter and trace the outer rim so that it stays in the correct position. Have a second person hold the sink in place while you run a bead of Copper Sink Installation Silicone around the outer rim. Drag your finger around the outer rim to smooth out the silicone.

6) Wipe any excess silicone off the countertop using a clean dry rag.
Allow to dry for 24 HOURS before using your sink.